

2SS-MSJ- U 6:1 / SSE-1 / 000-2 / FT / 24.5 / SB

INCH STAINLESS STEEL MACHINE SCREW JACKS TECHNICAL DATA

SS MACHINE SCREW MODEL

Ton	Model #
0.66	= 2SS-MSJ
1.67	= 5SS-MSJ
3.33	= 10SS-MSJ
5.00	= 15SS-MSJ
6.66	= 20SS-MSJ
8.30	= 25SS-MSJ
11.66	= 35SS-MSJ

CONFIGURATION

- U** = Upright
- I** = Inverted
- UR** = Upright Rotating
- IR** = Inverted Rotating

GEAR RATIO

Refer to product pages for available ratios.


SHAFT ORDER CODE

- CCW Position 1
- CW Position 2

ORDER CODES (Must Include A Position)

NO ACCESSORY

- SSE-** = Standard Shaft Extension, Position 1 or 2
- 000-** = Delete Shaft Extension, Position 1 or 2
- SPC-** = Special Modified Shaft Extension, Position 1 or 2



NOTE: Both Shaft Extensions Must Be Specified

HOUSING CONFIGURATION

- F** = Standard Flange Base

SCREW CONFIGURATION


TRANSLATING - U and I MODELS

- T** = Standard Threaded End
- C** = Clevis End
- P** = Top Plate


ROTATING - UR and IR MODELS

- A** = Travel Nut Position "A"
- B** = Travel Nut Position "B"

UR - Upright Rotating **IR** - Inverted Rotating



Travel Nuts shown in position "A"



TRAVEL

TRANSLATING - U and I MODELS
use actual Travel in inches.

ROTATING - UR and IR MODELS
use "L" Dimension in Inches.

MODIFIER LIST

S or M Required

- S** = Standard, no additional description required
- M** = Modified, additional description required

E, B and/or H Optional

- E** = In-Line Encoder (motor or motor mount required)
- B** = Bellows Boots (must calculate retracted and extended boot length, see page 280-281)
- H** = Hardened Worm